

PRESET CONFIGURATION
BEHRINGER MIDI FOOT CONTROLLER FCB1010

press "DOWN" for 3 sec. to enter
Preset Configuration

select Switches

press "UP" to confirm

SELECT	NUMBER	VALUE 1	VALUE 2
	<input type="text"/>	<input type="text"/>	<input type="text"/>


press 3 sec. to activate/deactivate

press once to select


press "UP" to confirm

adjust "NUMBER" using EXP pedal A or buttons 1...10

press "UP" to confirm

SELECT	NUMBER	VALUE 1	VALUE 2
adjust "VALUE 1" using EXP pedal A or buttons 1...10	<input type="text"/>		<input type="text"/>

press "UP" to confirm

SELECT	NUMBER	VALUE 1	VALUE 2
<input type="text"/>	<input type="text"/>	<input type="text"/>	

adjust "VALUE 2" using EXP pedal A or buttons 1...10

press "UP" to confirm

SELECT	NUMBER	VALUE 1	VALUE 2
	<input type="text"/>	<input type="text"/>	<input type="text"/>

press "DOWN" for 3 sec. to store preset

GLOBAL CONFIGURATION
BEHRINGER MIDI FOOT CONTROLLER FCB1010

